



TECHNICAL DATA

EASY RISER® SWING CHECK VALVE MODELS E-1 & F-1

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com

1. DESCRIPTION

The Viking Easy Riser® Swing Check Valve is a general purpose rubber-faced check valve approved for use in fire service systems. The valve is for use in wet system risers, preaction system risers and wherever a check valve with a drain connection and gauge connections can be utilized. When used with a flow switch on wet pipe systems not requiring a mechanical alarm, the Easy Riser® Swing Check Valve may replace an alarm check valve.

1-A Features

1. Ductile iron body for less weight and extra strength.
2. Rated to 300 psi (20.7 bar) water working pressure.
3. Rubber-faced clapper hinged to access cover for quick removal and easy servicing. All moving parts can be serviced without removing the valve from the installed position.
4. With the cover/clapper assembly removed, clapper rubber replacement requires removal of only one screw.
5. Valve housing tapped for inlet and outlet pressure gauges, and system main drain.

1-B Accessories

300 PSI (20.7 bar) Trim Package including:

- A. All necessary nipples and fittings
- B. Main Drain Ball Valve
- C. Necessary gauges



2. LISTINGS AND APPROVALS:

cULus Listed: HMER

FM Approved: Single Check Valves

NYC Department of Buildings: MEA 89-92-E, Vol. XI

VNIPO (250 psi (17.2 bar) MWP)

CE: Pressure Equipment Directive 97/23/EC (250 psi (17.2 bar) MWP)

3. TECHNICAL DATA

Specifications:

Standard Flanged Connections: ANSI B16.42 Class 150 (mates with ANSI Class 125 and Class 150 flanges).

Standard Grooved Connections: ANSI/AWWA C606

Drain outlet: 2-1/2" and 3" valves - one 1-1/4" (32 mm) NPT; 4", 6" & 8" valves - 2" (50 mm) NPT

Gauge Outlets: two 1/4" (8 mm) NPT

Other Outlets: two 1/2" (15 mm) NPT

Systems with water working pressures above 175 psi (12 bar) may require extra-heavy pattern fittings. Viking Easy Riser® Swing Check Valve flanges are Ductile Iron ANSI B16.42, Class 150, with a maximum water working pressure of 300 psi (20.7 bar). ANSI B16.42, Class 150 flanges are NOT compatible with ANSI Class 250 or Class 300 flanges. To mate the Easy Riser® Swing Check Valve with ANSI Class 250 or Class 300 flanges, use the grooved-inlet/grooved-outlet style installed with listed grooved/flanged adapters of the appropriate pressure rating. For piping with grooved connections, the grooved-inlet and/or grooved-outlet style Easy Riser® Swing Check Valve may be installed with listed grooved couplings of the appropriate pressure rating.

Material Standards:

Refer to Figure 1.

Ordering Information:

See Table 1 for part numbers and shipping weights.



TECHNICAL DATA

EASY RISER® SWING CHECK VALVE MODELS E-1 & F-1

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com

4. INSTALLATION

The Easy Riser® Swing Check Valve must be installed in an area not subject to freezing temperatures or physical damage. When corrosive atmospheres and/or contaminated water supplies are present, it is the owner's responsibility to verify compatibility with the Easy Riser® Swing Check Valve, trim, and associated equipment.

Prior to installing the valve, thoroughly flush the water supply piping to verify that no foreign matter is present.

The Easy Riser® Swing Check Valve may be installed in the vertical position with direction of flow up, or in the horizontal position with the access cover up.

1. Remove all plastic thread protectors from the openings of the Easy Riser® Swing Check Valve.
2. Apply a small amount of pipe-joint compound or tape to the external threads of all pipe connections required. Take care not to allow any compound, tape, or other foreign matter inside any of the nipples or openings of the valve or trim components.
3. Easy Riser® Swing Check Valve Trim Charts are provided with Trim Packages and on the Viking website.
4. Verify that all system components are rated for the water working pressure of the system.

Hydrostatic Test:

The Easy Riser® Swing Check Valve is manufactured and listed for use at a maximum water working pressure of 300 psi (20.7 bar). The valve is factory tested at 600 psi (41.4 bar). Easy Riser® Swing Check Valves may be hydrostatically tested at 350 psi (24.1 bar) and/or 50 psi (3.5 bar) above the normal water working pressure for limited periods of time (two hours) for the purpose of acceptance by the Authority Having Jurisdiction. If air testing is required, DO NOT exceed 40 psi (2.8 bar) air pressure.

5. OPERATION (Refer to Figure 1.)

Water flowing through the Viking Easy Riser® Swing Check Valve lifts the rubber-gasketed clapper (8 and 9) off the seat (12) and flows into the sprinkler piping. When flow through the valve stops, the clapper (8) closes quickly. The rubber gasket (9) forms a tight seal against the brass water seat (12), trapping pressurized water above the clapper and preventing reverse flow from the sprinkler piping.

6. INSPECTIONS, TESTS, AND MAINTENANCE

NOTICE

The owner is responsible for maintaining the fire protection system and devices in proper operating condition.

The Viking Easy Riser® Swing Check Valve and trim must be kept free of foreign matter, freezing conditions, corrosive atmospheres, contaminated water supplies, and any condition that could impair its operation or damage the device.

It is imperative that the system be inspected and tested on a regular basis. The frequency of the inspections may vary due to contaminated water supplies, corrosive water supplies, and corrosive atmospheres. For minimum maintenance and inspection requirements, refer to NFPA 25. In addition, the Authority Having Jurisdiction may have additional maintenance, testing, and inspection requirements that must be followed.

WARNING

Any system maintenance that involves placing a control valve or detection system out of service may eliminate the fire protection capabilities of that system. Prior to proceeding, notify all Authorities Having Jurisdiction. Consideration should be given to employment of a fire patrol in the affected areas.

6-A. Five-Year Internal Inspection

Internal inspection of check valves is recommended every five years unless inspections and tests indicate more frequent inspections are required. (Refer to Figure 1.)

1. Notify the Authority Having Jurisdiction, remote station alarm monitors, and those in the area affected that the system will be taken out of service. Consideration should be given to employment of a fire patrol in the affected areas.
2. Close the water supply main control valve, placing the system out of service.
3. Open the main drain. If necessary, open the system test valve to vent and completely drain the system.
4. Use the appropriate wrench to loosen and remove cover screws (14), and remove cover and clapper assembly (2-11).
5. Inspect water seat (12). Wipe away all contaminants, dirt, and mineral deposits. DO NOT use solvents or abrasives.
6. Inspect cover and clapper assembly (2-11) and cover gasket (13). Test the hinged clapper (8) for freedom of movement. Renew or replace damaged or worn parts as required.



TECHNICAL DATA

EASY RISER® SWING CHECK VALVE MODELS E-1 & F-1

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com

⚠ CAUTION

NEVER apply any lubricant to seats, gaskets, or any internal operating parts of the valve. Petroleum-based grease or oil will damage rubber components and may prevent proper operation.

7. When internal inspection of the Easy Riser® Swing Check Valve is complete, perform step 6 of paragraph 11. MAINTENANCE to re-install cover and clapper assembly (2-11).

6-B. Maintenance (Refer to Figure 1.)

1. Perform steps 1 through 5 of paragraph 6-A, FIVE-YEAR INTERNAL INSPECTION.
2. To replace clapper assembly (3, 6-11):
 - a. Remove the cover screws (14) from the cover (2) using a Socket Wrench with a 9/16" socket.
 - b. Remove the cover and clapper assembly (2-11) from the valve.
 - c. Remove the cover gasket (13) by sliding it over the clapper assembly.
 - d. Remove the existing clapper assembly (3, 6-11) from the cover assembly (2):
 - i. Remove one of the retaining rings (5) from the clapper hinge pin (4) using a flat head screwdriver.
 - ii. Remove the clapper hinge pin (4) from the cover and clapper assembly. This will allow the clapper assembly (3, 6-11) to be removed from the cover assembly (2).
 - e. Install the new clapper assembly (3, 6-11) onto the cover assembly (2):
 - i. Make sure the clapper rubber (9) is facing opposite the direction of the flow arrow on the inside of the cover (2).
 - ii. Line up the holes of the cover assembly (2) and the clapper assembly (3, 6-11) and insert the hinge pin (4).
 - iii. Install the retaining ring (5) onto the hinge pin (4).
 - iv. Install the cover gasket (13) onto the new cover and clapper assembly (2-11) by sliding the cover gasket (13) over the clapper assembly (3, 6-11) and lining up the holes with the cover (2).
 - v. To install the new cover and clapper assembly (2-11) into the valve, slide the clapper assembly into the valve with the clapper rubber (9) lined up with the water seat (12). Ensure the rubber retainer (10) fits inside the seat of the valve (pull back slightly and there should be some resistance).
 - vi. Line up the holes of the cover (2) and cover gasket (13) with the valve body (1) and replace the cover screws (14) using a Socket Wrench with a 9/16" socket.
3. To replace the clapper rubber (9):
 - i. Remove the cover screws (14) from the cover (2) using a Socket Wrench with a 9/16" socket.
 - ii. Remove the cover and clapper assembly (2-11) from the valve.
 - iii. Remove the cover gasket (13) by sliding it over the clapper assembly (3, 6-11).
 - iv. Use a 7/32" Allen wrench to hold the button head socket screw (11) in place and remove the jam nut (6) from the clapper rubber (9) using a Socket Wrench with a 9/16" socket.
 - v. Remove the button head socket screw (11) and sealing washer (7) from the clapper assembly (3, 6-11).
 - vi. Remove the clapper rubber retainer (10) from the clapper (8) to free the clapper rubber (9).
 - vii. To install the new clapper rubber (9), position the clapper rubber (9) on the clapper assembly so the grooved edge is facing down. This will allow the clapper rubber retainer (10) to fit up into the grooved edge of the clapper rubber (9).
 - viii. Install the button head socket screw (11) and sealing washer assembly (7) and the jam nut (6) using a 7/32" Allen wrench and a Socket Wrench with a 9/16" socket.
 - ix. Install the cover gasket (13) onto the cover (2) by sliding it over the clapper assembly (3, 6-11).
 - x. Re-install the cover and clapper assembly (2-11) back into the valve, with the clapper rubber (9) lined up with the water seat (12). Ensure the clapper rubber retainer (10) fits inside the seat of the valve (pull back slightly and there should be some resistance).
 - xi. Line up the holes of the cover (2) and cover gasket (13) with the valve body (1) and replace the cover screws (14) using a Socket Wrench with a 9/16" socket.
4. To replace the cover gasket (13):
 - i. Remove the cover screws (14) from the cover (2) using a Socket Wrench with a 9/16" socket.
 - ii. Remove the cover and clapper assembly (2-11) from the valve.
 - iii. Remove the cover gasket (13) by sliding it over the clapper assembly (3, 6-11).
 - iv. Install the new cover gasket (13) by sliding it over the clapper assembly (3, 6-11), onto the cover (2).
5. Reinstall the cover and clapper assembly (2-11) into the valve:
 - i. Line up the clapper rubber (9) with the water seat (12). Ensure the clapper rubber retainer (10) fits inside the seat of the valve (pull back slightly and there should be some resistance).
 - ii. Line up the holes of the cover (2) and cover gasket (13) with the valve body (1) and replace the cover screws (14) using a Socket Wrench with a 9/16" socket.



TECHNICAL DATA

EASY RISER® SWING CHECK VALVE MODELS E-1 & F-1

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com

7. AVAILABILITY

The Viking Easy Riser® Swing Check Valve is available through a network of domestic and international distributors. See the Viking Corp. Web site for closest distributor or contact The Viking Corporation.

8. GUARANTEES

For details of warranty, refer to Viking's current list price schedule or contact Viking directly.

Table 1 - Valve Part Numbers and Specifications

Description	Nominal Size	Part Number	Friction Loss*	Shipping Weight
Flange/Flange				
Flange Drilling	Model F-1			
ANSI	3"	08505	10 ft. (3.1 m)	35 lbs. (16 kg)
ANSI	4"	08508	13 ft. (4.0 m)	44 lbs. (20 kg)
ANSI	6"	08511	20 ft. (6.0 m)	75 lbs. (34 kg)
ANSI/Japan	DN100	09039	13 ft. (4.0 m)	44 lbs. (20 kg)
ANSI/Japan	DN150	09385	20 ft. (6.0 m)	75 lbs. (34 kg)
ANSI/Japan	DN200	14023	23 ft. (7.0 m)	119 lbs. (54 kg)
PN10/16	DN80	08796	10 ft. (3.1 m)	35 lbs. (16 kg)
PN10/16	DN100	08797	13 ft. (4.0 m)	44 lbs. (20 kg)
PN10/16	DN150	08835	20 ft. (6.0 m)	75 lbs. (34 kg)
PN10	DN200	08836	23 ft. (7.0 m)	119 lbs. (54 kg)
PN16	DN200	12355	23 ft. (7.0 m)	119 lbs. (54 kg)
Flange/Groove				
Flange Drilling / Pipe O.D.	Model F-1			
ANSI / 89mm	3"	08506	10 ft. (3.1 m)	27 lbs. (12 kg)
ANSI / 114mm	4"	08509	13 ft. (4.0 m)	37 lbs. (17 kg)
ANSI / 168mm	6"	08512	20 ft. (6.0 m)	64 lbs. (29 kg)
ANSI / 219mm	8"	08515	23 ft. (7.0 m)	119 lbs. (54 kg)
PN10/16 / 89mm	DN80	12648	10 ft. (3.1 m)	27 lbs. (12 kg)
PN10/16 / 114mm	DN100	12649	13 ft. (4.0 m)	37 lbs. (17 kg)
PN10/16 / 165mm	DN150	12652	20 ft. (6.0 m)	64 lbs. (29 kg)
PN10/16 / 168mm	DN150	08512	20 ft. (6.0 m)	64 lbs. (29 kg)
PN10 / 219mm	DN200	12651	23 ft. (7.0 m)	119 lbs. (54 kg)
PN16 / 219mm	DN200	12650	23 ft. (7.0 m)	119 lbs. (54 kg)
Groove/Groove				
Pipe O.D.	Model E-1			
73mm	2½" / DN65	07929	6 ft. (1.8 m)	16 lbs. (7 kg)
76 mm	2½" / DN65	13516	6 ft. (1.8 m)	16 lbs. (7 kg)
	Model F-1			
89mm	3" / DN80	08507	10 ft. (3.1 m)	20 lbs. (9 kg)
114mm	4" / DN100	08510	13 ft. (4.0 m)	27 lbs. (12 kg)
165mm	DN150	12356	20 ft. (6.0 m)	51 lbs. (23 kg)
168mm	6" / DN150	08513	20 ft. (6.0 m)	51 lbs. (23 kg)
219mm	8" / DN200	08516	23 ft. (7.0 m)	106 lbs. (48 kg)

*Expressed in equivalent length of Schedule 40 pipe based on Hazen & Williams formula: C = 120.

Table 2 - Torque Values for Easy Riser Swing Check Valve Cover Screws

Valve Size	Screw Size	Torque Value
2-1/2" (DN65)	3/8"-16 H.H.C.	19 ft-lb (2.63 kg-m)
3" (DN80)	3/8"-16 H.H.C.	19 ft-lb (2.63 kg-m)
4" (DN100)	3/8"-16 H.H.C.	19 ft-lb (2.63 kg-m)
6" (DN150)	½"-13 H.H.C.	45 ft-lb (6.23 kg-m)
8" (DN200)	5/8"-11 H.H.C.	93 ft-lb (12.9 kg-m)

Table 3 - Trim Package Part Numbers

Valve Size	Part Number
Wet System Trim Packages	
2-1/2", 3" (DN65), (DN80)	07236
4", 6", 8", (DN100), (DN150), (DN200)	07237
Preaction System Trim Packages	
2-1/2", 3" (DN65)	13776
4", 6", 8", (DN80), (DN100), (DN150), (DN200)	13777




TECHNICAL DATA

EASY RISER® SWING CHECK VALVE MODELS E-1 & F-1

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com



SIZE	A	B	C	D	E	F	G**
2-1/2" (65mm)	9" (228,6)	4-1/2" (114,3)	2-5/8" (66,7)	2" (50,8)	2" (50,8)	Flg-Flg Not Available	
3" (80mm)	10-1/8" (257)	4-13/16" (122,2)	2-11/16" (68,3)	2-9/32" (58,1)	2-9/32" (58,1)	7-7/8" (200)	25/32" (20)
4" (100mm)	10-5/8" (269,9)	5-3/16" (131,8)	3-1/8" (79,4)	2-1/4" (57,2)	2-1/4" (57,2)	9" (228,6)	15/16" (25,81)
6" (150mm)	13-3/8" (340)	6-13/16" (173,3)	4-1/16" (103,2)	2-1/4" (57,2)	2-1/4" (57,2)	11" (279,4)	1" (25,4)
8" (200mm)	17" (431,8)	8-13/16" (223,4)	5" (127)	2-1/2" (63,4)	2-7/8" (73,0)	13-1/2" (342,9)	1-1/8" (28,58)

Dimensions shown in parentheses are millimeter.

* For availability of Flg X Flg, Flg X Grv, or Grv X Grv options refer to Table 1.

** 4", 6", and 8" valves are manufactured with sculptured flanges. Dimension indicates thickness of flange at bolt holes.

Figure 1 - Replacement Parts

ITEM NO.	PART NUMBER					DESCRIPTION	MATERIAL	NO. REQ'D				
	E-1	F-1	F-1	F-1	F-1							
	2-1/2" (DN65)	3" (DN80)	4" (DN100)	6" (DN150)	8" (DN200)			2-1/2"	3"	4"	6"	8"
1	--	--	--	--	--	Body	Ductile Iron, ASTM A536 (65-45-12)	1	1	1	1	1
2	--	--	--	--	--	Cover Assembly	E-Coated HSLA Steel, A715 and Stainless Steel, UNS-S30400	1	1	1	1	1
3	07576	07576	07576	07576	None	Bushing	Lubricomp 189 Ryton	2	2	2	2	0
4	05355A	05355A	04900A	04991A	05334A	Clapper Hinge Pin	Stainless Steel, UNS-S30400	1	1	1	1	1
5	05445A	05445A	05445A	05445A	05369A	Hinge Pin Retaining Ring	Stainless Steel, UNS-S15700	2	2	2	2	2
6	01755A					Clapper Hex Jam Nut #10-24 UNC	Stainless Steel, UNS-S30400	1	0	0	0	0
		08159	08159			Clapper Hex Jam Nut 3/8"-24 UNF	Stainless Steel, UNS-S30400	0	1	1	0	0
				08144	08144	Clapper Hex Jam Nut 1/2"-20 UNF	Stainless Steel, UNS-S30400	0	0	0	1	1
7	--	08158	08158	08143	08143	Sealing Washer	EPDM and Stainless Steel	1	1	1	1	1
8	*	*	*	*	*	Clapper	PTFE Coated HR Steel UNS-G10180	1	1	1	1	1
9	*	*	*	*	*	Clapper Rubber	EPDM, ASTM D2000	1	1	1	1	1
10	*	*	*	*	*	Clapper Rubber Retainer	Stainless Steel, UNS-S30400	1	1	1	1	1
11	06595A					H.H.C. Screw, #10-24 UNC x 1/2" (12.7 mm) lg.	Stainless Steel, UNS-S30400	1	0	0	0	0
		10194	10194			Screw, Button Head, Socket, 3/8" - 24 UNF x 1/2 (12.7 mm) lg.	Stainless Steel, UNS-S30400	0	1	1	0	0
				10308		Screw, Button Head, Socket, 1/2" - 20 UNF x 3/4 (19.1 mm) lg.	Stainless Steel, UNS-S30400	0	0	0	1	0
					10686	Screw, Button Head, Socket, 1/2" - 20 UNF x 7/8 (22.2 mm) lg.	Stainless Steel, UNS-S30400	0	0	0	0	1
12	--	--	--	--	--	Seat	Brass, UNS-C84400	1	1	1	1	1
13	05354B	05354B	04649B	04992B	05339C	Cover Gasket	EPDM, ASTM D2000	1	1	1	1	1
14	01517A	01517A	01517A			Screw, Hex Head Cap, 3/8" - 16 UNC x 3/4 (19.1 mm) lg.	Steel, Zinc Plated	4	4	6	0	0
				04993A		Screw, Hex Head Cap, 1/2" - 13 x 7/8 (22.2 mm) lg.	Steel, Zinc Plated	0	0	0	6	0
					01922A	Screw, Hex Head Cap, 5/8" - 11 UNC x 1-1/4" (31.8 mm) lg.	Steel, Zinc Plated	0	0	0	0	6
15	--	--	--	--	--	1/2" (15 mm) NPT Pipe Plug	Steel	2	2	2	2	2

-- Indicates replacement part is not available

* Indicates replacement part only available in a Sub-Assembly listed below.

Sub-Assemblies

3, 6-11	05499B	08518	08519	08520	08521	Clapper Assembly
6, 7, 9, 11, 13	06343A	08522	08523	08524	08525	Replacement Rubber Kit




TECHNICAL DATA

EASY RISER® SWING CHECK VALVE MODELS E-1 & F-1

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com



2-1/2" MODEL E-1
EASY RISER CHECK VALVE
TRIM CHART

3", 4", 6", & 8" MODEL F-1
EASY RISER CHECK VALVE
TRIM CHART

Note 1: 300 psi (20.7 bar) water pressure gauges are provided with trim. 600 psi (41.4 bar) water pressure gauges are available. Order separately when needed*. Refer to Viking's current price schedule.

* NFPA 13 requires gauges to have a minimum limit not less than twice the normal water working pressure at the point where the gauges are installed. When normal water working pressure exceeds 150 psi (10.3 bar), order 600 psi (41.4 bar) water pressure gauges separately.

Note 2: System Drain Ball Valve is UL Listed and FM Approved for 300 psi (20.7 bar) water working pressure.



TECHNICAL DATA

EASY RISER® SWING CHECK VALVE MODELS E-1 & F-1

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com

